GLDE



THE **BRADLEY** COLLECTION

CURTAIN MAKEUP GUIDE SINE GLIDERS • RIPPLE ROLLERS

CURTAIN MAKEUP GUIDE

SINE GLIDERS • RIPPLE ROLLERS

Many workrooms will have their own method of manufacturing wave-shaped curtains. This guide is intended to give you a suggested make up method.

When using your own fabrics we suggest that sample curtains are made to determine whether, It is suitable to create wave-shaped curtains.

In general, stiffer fabrics tend not to lend themselves to the wave-shape since they struggle to hold the soft curves For the drop of the curtain.

Once you have confirmed your fabric is suitable, you may want to consider using lead weight tape and curtain side weights for an improved finished appearance.

The maximum weight that the pocketed heading tape can carry with gliders is 2.5kg per metre of track. With roller cord has much higher weight limitations. However, individual track weight restrictions still apply.

Fabric Page 2 Essential Parts Page 3 Glider & Roller Spacing Page 4 Header Tape Calculation Page 5 Making Wave-Shaped Curtains Page 6 Hook Placement & Dressing the Curtains Page 7

THE **BRADLEY** COLLECTION

There is no standard test that will indicate whether a fabric is suitable for wave-shaped curtains. However, experience suggests it is normally suitable for Voiles • Lined cotton • Interlined Silk • Blackout lining

The soft curves do not lend themselves to:

imes Stiff fabrics ullet Heavy embroidery ullet Irregular vertical stripes ullet Metallic threads

We recommend a simple test to indicate whether fabric will be suitable (see image right). Hold the top of the fabric in this way and see if the curtain follows a soft wave-shaped pattern without too much effort.

Wave-shaped curtains will require some dressing and training. The extent of this will depend on the flexibility of the weave of the fabric chosen.

✓ SUITABLE FABRIC


× UNSUITABLE FABRIC



ESSENTIAL PARTS

SINE GLIDERS

Gliders are suitable for most installations. **Sine Pitch:** 80mm (31/8") **Colour Options:** Gypsum • Anthracite



METALCOAT SINE GLIDERS

Gliders are suitable for most installations. Sine Pitch: 80mm (31/8 ") Colour Options: System Colour (S) • Brushed Nickel


RIPPLE ROLLERS


Rollers are preferred for heavy drapery. **Ripple Pitch:** 80mm (31/8") **Ripple Roller Colour Options:** White • Black




POCKETED HEADING TAPE

Various heading tapes are available to produce wave-shaped curtains, Double row tape can be supplied on request. Colour Options: White • Black







SINGLE ROW


TOP & BOTTOM ROW

CURTAIN HOOKS Colour Options: White • Black



DOUBLE ROW





CURTAIN WEIGHT CORD



GLIDER & ROLLER SPACING

(!)

The curtain fullness indicated below and throughout this guide applies to finished curtain fabric. You will need to allow additional fabric for joins hems and your usual workroom allowances

SINE GLIDERS

Sine Pitch: 80mm (31/8") Colour Options: Gypsum • Anthracite

- P	
19	
Ø	Ø

Glider	Curtain Hook	Pocket	Approx. Curtain	Stack Width	Stack Depth	Min Bracket
Spacing	Spacing	Spacing	Fullness	per 1M (39 ³ / ₈ ") of pole	Front to Back	Projection
80mm (31⁄8″)	160mm (65⁄16″)	7	2.3	180mm (7½″)	160mm (6⁵⁄1₀″)	100mm (4″)


RIPPLE ROLLERS

Ripple Pitch: 80mm (31/8")

Ripple Roller Colour Options: White • Black

Roller	Curtain Hook	Pocket	Approx. Curtain	Stack Width	Stack Depth	Min Bracket
Spacing	Spacing	Spacing	Fullness	per 1M (39¾") of pole	Front to Back	Projection
80mm (31⁄8″)	160mm (65⁄16″)	7	2.3	180mm (7¼16″)	160mm (6⁵⁄1₀″)	100mm (4″)

POCKET SPACING



CALCULATE THE LENGTH OF THE HEADER TAPE

Check your order paperwork, the number of Sine Gliders/Ripple Rollers the system should be listed.

If you can not find this information please call to sales desk, who will be happy to help.

Alternatively use the number of gliders calculated from the previous stage to determine the length of your heading tape.

Do not cut your fabric until you have confirmed the length of the heading tape

To calculate how much heading tape you require, visit **www.bradleycollection.com/downloads**/ and download the Drive Sine/Ripple Calculator This tool automatically calculates the heading tape required.

1 Select Glide

(!)

(!)

- 2 Select single or pair stack
- 3 Input the pole length
- 4 See calculated Hooking Points and Pocket total

-	The MILLIN PLAN	1 1 2 Pr 1 Press - 1000	1 1 2 2 2	EE.	1 12 W B	
1	1	12.8.1				
	The Bradey Columbus Wave Non Calculat	er - Inin	-			the second s
ł	Child an yelfow boson to subset or other dat	une .	Metric		Customer Order Ref	
87	Solar	Glide				
1	Par or origin stars	5				
1	Single Motor or Twit Mater		-			
1.	Laft in High					
1	Potencia	1500	mm			
14	Gitter cast / hold spacing	BOmm 160mm				
0.0						
	Calculated number of bushing patrix per surfa-		20			
2		satain. The includes 2 postate such and for hermitig	163			
E						


Pockets should be counted Not measured Do not cut your fabric yet!

MAKING WAVE-SHAPED CURTAINS

Fold two


pockets in

Sewing




2 Turn in 2 pockets at each end of the tape. Now you have your finished curtain width, measure this to cut your fabric.

3 We recommend that you use an iron tape to avoid fabric puckering and give a professional finish to the top hem.



The tape can now be sewn to the top of the curtain.
This needs to be set 12mm (½") from the top of the curtain.
This has been calculated to give the correct hook drop when sewn in position.

HEADER TAPE POSITION



HOOK PLACEMENT & DRESSING THE CURTAINS


CURTAIN DRESSED INCORRECTLY

5 Insert the hooks based on the diagrams below.

(!) Standard Pocket Spacing is 7. Leave 7 empty pockets between hooks If pocketed tape has 2 sets of pockets use the top set of pockets

STANDARD SPACING BETWEEN CURTAIN EDGES

Leave 7 empty pockets between hooks



6 When hanging the curtain pull the first fold towards you and the second away from you.

CURTAIN DRESSED CORRECTLY



If the fabric does not automatically fall into the wave-shape at the bottom we recommend you try using a lead weight cord in the hem and fabric side weights.

.....



www.bradleycollection.com



UK & REST OF THE WORLD

LONDON SHOWROOM

- 0 14 (0)207 871 7703
- 🛷 showroom@studiotwochelsea.com

USA & CANADA

𝔄 +1 (310) 815 8255
𝒜 info.us@bradleycollection.com

THE **BRADLEY** COLLECTION





Specialised fixings for mounting brackets will be required in certain situations and are not provided as standard. Steel items are not recommended for damp conditions such as shower rooms. Crystal finials should not be positioned in direct sunlight, and are not suitable for use in conservatories. Fluid Metal items are supplied unlacquered and will tarnish over time.

The Bradley Collection reserves the right to modify design and materials without prior notice as part of a process of continual product improvement. Due to printing limitations, colours in this brochure may not be accurate.

Products are protected by Design Rights, under provisions of Copyright, Designs & Patents Act 1988. Bradley[®], The Bradley Collection[®] and \bigcirc Logo are registered Community trademarks of The Bradley Collection Ltd. in Europe and registered trademarks of the Bradley Collection, Inc. in the USA.

The Bradley Collection Ltd Lion Barn • Maitland Road • Needham Market • Suffolk • IP6 8NS • UK